

# WYKAZ STOLARKI OKIENNEJ DO WYMIANY

Numer	1	2	3	4	5
Symbol	O1	O2	O3	O4	O5
Wymiary	900/900	2700/900	1200/1750	2700/1750	1500/1750
Ilość: parter	5	1	8	4	18
Ilość: piwnica	-	-	-	-	-
Razem	5	1	8	4	18

Numer	6	7	8
Symbol	O6	O7	O8
Wymiary	2500/1750	900/1750	1100/900
Ilość: parter	1	1	1
Ilość: piwnica	-	-	-
Razem	1	1	1

Numer	12	13	14	16
Symbol	O12	O13	O14	O16
Wymiary	1500/900	900/600	1500/600	2700/600
Ilość: parter	1	-	-	-
Ilość: piwnica	-	5	24	1
<b>Razem</b>	<b>1</b>	<b>5</b>	<b>24</b>	<b>1</b>